# **TECHNICAL PAMPHLET**



**RECKLI Supporting Mass** 

**EP-F Type L** Product 07191 Edition 12/16

**RECKLI® Supporting Mass EP-F Type L** 

modified epoxy resin, glass fibre reinforced

# **PROPERTIES**

RECKLI Supporting Mass EP-F Type L is a glass fibre reinforced, solvent-free twocomponent epoxy resin with low density. When cured, it shows high impact resistance and dimensional stability under heat.

# **APPLICATIONS**

RECKLI Supporting Mass EP-F Type L is suitable for manufacturing rigid, light supporting moulds as used along with thin-walled elastic moulds out of polyurethane or silicone rubber when replicating ornaments, figures or monuments. It can also be used for making light and yet very stable backfillings of rigid moulds for construction-, ceramic- or porcelain-industry.

#### **TECHNICAL DATA**

property	value	method
mixing ratio (base : hardener):	7:1	(according to weight)
workable temperature:	+10 °C – +30 °C	
pot life (1000-g-mixture at +21 °C):	approx. 30 – 40 min	
density:	0,95 g/cm³	
dimensional stability under heat:	85 °C	DIN 53462
heat resistance (dry heat):	+100 °C	

These data are typical guide values. They are not destined for the generation of specifications.

# SURFACE PREPARATION

On humid surfaces, such as gypsum or clay, a preceding treatment with RECKLI Si Stripping Lacquer is recommended. When making supporting moulds, at least two layers of RECKLI Mould Wax should be applied onto the entire mould surface ensuring an easy separation of the single parts.

To ensure good adhesion, backfillings out of RECKLI Supporting Mass EP-F Type L must be applied if the primary layer is still wet but not displaceable any more.

#### PROCESSING

homogenously. e material tends bowww.reckli.de

RECKLI GmbH

Add the hardener (B) to the base component (A) and knead them homogenously. For mixing, a kneader is more suitable than an agitator, because the material tends



**RECKLI Supporting Mass** 

EP-F Type L

Product 07191 Edition 12/16

to coil around the mixing rod. When kneading small quantities by hand, wear suitable protective gloves.

Subsequently the mass is applied and compacted with a trowel, a scraper or by hand. RECKLI Supporting Mass EP-F Type L is most easily applied when the ready mixed material is rolled out between two foils to the required thickness. Right before placing, the first foil is removed, the second one after pressing the mass onto the substrate.

The recommended layer thickness is 5 – 10 mm per application. To increase the stiffness and the breaking strength of particularly large moulds, additional armouring or reinforcement out of steel or timber should be embedded. Likewise, provide supports ensuring the mould is standing level when turned. To achieve good adhesion, bare metal or coated wood must be roughened by grinding.

To protect against injuries, protruding glass fibres and sharp edges must be removed. When fresh, the material can be smoothed with RECKLI Epoxy OH. To avoid skin contact, wear disposable gloves. When cured, the surface can be smoothed with a grinding machine. Avoid breathing grinding dust; if necessary, wear a dust mask.

#### **CONSUMPTION**

9,5 kg/m<sup>2</sup> per cm thickness.

#### **CLEANING OF EQUIPMENT**

For the cleaning of the tools and the equipment, use dry, absorbing cloths, if necessary RECKLI Epoxy Cleanser in addition. Immersion in solvents is not sufficient.

# **PACKAGING SIZES**

drums: 4 kg

The hardener is enclosed in the drum in a separate bottle.

# **STORAGE**

Store in a dry place at room temperature. RECKLI Supporting Mass EP-F Type L is storable for 6 months from delivery when kept in the closed original packaging at about 18 °C. Opened drums must be closed airtight right after use.

#### SPECIAL REMARKS

#### **RECKLI GmbH**

Storage at low temperatures may cause partial crystallisation of the base component, even if only parts of the container are exposed to cold. In this case, the material can be melted in the closed container at 40 - 50 °C. When mixed up, it is usable again.

Gewerkenstraße 9a D-44628 Herne Tel +49 2323 1706-0 Fax +49 2323 1706-50 info@reckli.de www.reckli.de

# **GENERAL INFORMATION**

For further information please also see:

"General advice for the processing of RECKLI two-component resins",

"General advice for making moulds and models using RECKLI two-component polyurethanes".

# SAFETY

Protect skin and eyes from material splashes. Wear suitable gloves for protection from resin-impregnated glass fibres. Provide sufficient ventilation in the working place. Please consult the relevant safety data sheet and attend to the indications on the label of the package regarding the Dangerous Goods Regulation. This pamphlet is intended solely as an application directive. It does not claim to be binding and valid for all modes of application. A preliminary test under operation conditions is highly recommended.

This pamphlet replaces all previously published pamphlets concerning RECKLI Supporting Mass EP-F Type L, stating them as no longer being valid. RECKLI Supporting Mass EP-F Type L Product 07191

DESIGN YOUR CONCRETE

Edition 12/16

#### **RECKLI GmbH**

Gewerkenstraße 9a D-44628 Herne Tel +49 2323 1706-0 Fax +49 2323 1706-50 info@reckli.de www.reckli.de